Quick Installation Guide

L2/L3 Superio Industrial Switch

SP3008FM-L2 V1/SP3010FM-L2 V1/SP3010FM-L2 V2/SP3018FM-L2 V2/SP5010FM-L2 V2/SS028M-16TBCsX-L3/SS028M-16SBCsX-L3

www.wintekio-itek.com

1.Packing Content

Switch x 1

Quick Installation Guide x 1

Phoenix Terminal x 2

(For SS028M-16TBCsX-L3/SS028M-16SBCsX-L3)

Power Cord x 1

(For SS028M-16TBCsX-L3/SS028M-16SBCsX-L3)

Mounting Accessories

(For SS028M-16TBCsX-L3/SS028M-16SBCsX-L3)

2. Appearance Overview

SP3008FM-L2 V1/SP3008FM-L2 V2

- Front Panel

8x10/100/1000 Base-T PoE Ports

2x1000/1000 Base-X SFP Ports

LED Indicators

For hardware V1: Port 1-8 support 802.3at/af PoE output.
For hardware V2: Port 1-2 support 802.3at/af PoE output, Port 3-8 support 802.3at/af PoE output.

- Side Panel

44~57V DC Power Supply Input (Main)

44~57V DC Power Supply Input (Backup)

Grounding Reset Console

- LED indicator and button

LED Indicators and Button	
P	ON: The switch is powered off or failed OFF: The switch is powered on and working
S	ON: device as normal operation OFF: Device failure detected Blinking: device initialization
Link	OFF: ports link down ON: ports link up
Act	OFF: no data is transmitted or received ON: data is transmitting or receiving
10, 100 (Fiber ports indicators)	ON: the link is connected with 10/100Mbps speed
Reset Button	By pressing the button over 5s, the switch will be restored to the original factory default setting.

SP3010FM-L2 V1/SP3010FM-L2 V2

- Front Panel

8x10/100/1000 Base-T PoE Ports

2x1000/2500 Base-X SFP Ports

LED Indicators

For hardware V1: Port 1-8 support 802.3at/af PoE output.
For hardware V2: Port 1-2 support 802.3at/af PoE output, Port 3-8 support 802.3at/af PoE output.

- Side Panel

44~57V DC Power Supply Input (Main)

44~57V DC Power Supply Input (Backup)

Grounding Reset Console

- LED indicator and button

LED Indicators and Button	
P	ON: The device is powered on OFF: The device is powered off or failed
S	ON: device as normal operation OFF: Device failure detected Blinking: device initialization
Link	OFF: ports link down ON: ports link up
Act	OFF: no data is transmitting or receiving ON: data is transmitting or receiving
2.5, 10 (Fiber ports indicators)	ON: the link is connected with 2.5/10Gbps speed
Reset Button	By pressing the button over 5s, the switch will be restored to the original factory default setting.

SP5010FM-L2 V1/SP5010FM-L2 V2

- Front Panel

8x10/100/1000 Base-T PoE Ports

4x100/1000 Base-X SFP Ports

LED Indicators

For hardware V1: Port 1-8 support 802.3at/af PoE output.
For hardware V2: Port 1-2 support 802.3at/af PoE output, Port 3-8 support 802.3at/af PoE output.

- Side Panel

44~57V DC Power Supply Input (Main)

44~57V DC Power Supply Input (Backup)

Grounding Reset Console

- LED indicator and button

LED Indicators and Button	
P	ON: The device is powered on OFF: The device is powered off or failed
S	ON: device as normal operation OFF: Device failure detected Blinking: device initialization
Link	OFF: ports link down ON: ports link up
Act	OFF: no data is transmitting or receiving ON: data is transmitting or receiving
1, 10, 25 (Fiber ports indicators)	ON: the link is connected with 1/10/25Gbps speed
Reset Button	By pressing the button over 5s, the switch will be restored to the original factory default setting.

SP3018FM-L2

- Front Panel

16x10/100/1000 Base-T PoE+ Ports

2x1000/2500 Base-X SFP Ports

LED Indicators

- Side Panel

44~57V DC Power Supply Input (Main)

44~57V DC Power Supply Input (Backup)

Grounding Reset Console

- LED indicator and button

LED Indicators and Button	
P	ON: The device is powered on OFF: The switch is powered off or failed
S	ON: device as normal operation OFF: Device failure detected Blinking: device initialization
Link	OFF: ports link down ON: ports link up
Act	OFF: no data is transmitting or receiving ON: data is transmitting or receiving
2.5, 10 (Fiber ports indicators)	ON: the link is connected with 2.5/10Gbps speed
Reset Button	By pressing the button over 5s, the switch will be restored to the original factory default setting.

SP5010FM-L2

- Front Panel

8x10/100/1000 Base-T PoE+ Ports

4x100/1000 Base-X SFP Ports

LED Indicators

- Side Panel

44~57V DC Power Supply Input (Main)

44~57V DC Power Supply Input (Backup)

Grounding Reset Console

- LED indicator and button

LED Indicators and Button	
P	ON: The device is powered on OFF: The switch is powered off or failed
S	ON: device as normal operation OFF: Device failure detected Blinking: device initialization
Link	OFF: ports link down ON: ports link up
Act	OFF: no data is transmitting or receiving ON: data is transmitting or receiving
1, 10, 25 (Fiber ports indicators)	ON: the link is connected with 1/10/25Gbps speed
Reset Button	By pressing the button over 5s, the switch will be restored to the original factory default setting.

SS028FM-16TBCsX-L3

- Front Panel

Reset

USB Console

4*10G SFP+ Ports

LED Indicators

8*100Mbps Combo SFP Ports

DC 36~75V IN

- Back Panel

AC 100~240V Power IN

- LED indicator and button

LED Indicators and Button	
P	ON: The switch is powered on OFF: The switch is powered off or power supply is abnormal
S	ON: device as normal operation Blinking: device initialization OFF: Device system abnormality
USB	ON: USB flash drive is connected to device OFF: USB flash drive not insert or not detected by device Blinking: data on USB flash drive is transmitting
Copper ports indicators	Blinking: data on TX/RX OFF: No data is transmitted
Copper speed indicators	Yellow on:The port is connected with 100Mbps speed OFF: The port is connected with 10/100Mbps speed
Fiber indicators	Blinking: Data transmission Steady On: No data is transmitted
Reset Button	By pressing the button over 5s, the switch will be restored to the original factory default setting.

SS028FM-16SBCsX-L3

- Front Panel

Reset

USB Console

4*10G SFP+ Ports

LED Indicators

8*100Mbps Combo SFP Ports

DC 36~75V IN

- Back Panel

AC 100~240V Power IN

- LED indicator and button

LED Indicators and Button	
P	ON: The switch is powered on OFF: The switch is powered off or power supply is abnormal
S	ON: device as normal operation Blinking: device initialization OFF: Device system abnormality
USB	ON: USB flash drive is connected to device OFF: USB flash drive not insert or not detected by device Blinking: data on USB flash drive is transmitting
Copper ports indicators	Blinking: data on TX/RX OFF: No data is transmitted
Copper speed indicators	Yellow on:The port is connected with 100Mbps speed OFF: The port is connected with 10/100Mbps speed
Fiber indicators	Blinking: Data transmission Steady On: No data is transmitted
Reset Button	By pressing the button over 5s, the switch will be restored to the original factory default setting.

3. Installation

- DIN-rail Installation

(For Superio L2 series switch)

- Desktop Installation

- Rack-Mount Installation

4.Management

· Log in to the switch locally

Try log in follow these steps:

1. Use the default management user type the default IP 192.168.0.1 in the address bar.
2. The login screen will appear. The default username and password are both admin.

Step 1 Download a PuTTY software

Step 2 Use the Console cable to connect the computer and the switch as shown in the above figure.

Step 3 Set the com port number of the Console line and the baud rate of the switch in the PuTTY configuration figure (same below).

Notice:

Step 3 Is your computer recognizes the COM number of the Console line

Step 3 Is the baud rate of the exchange line baud rate of the switch is 115200

· Use Telnet to log in to the CLI mode of the switch

Connection Diagram:

Step 1 Configure the IP address of the computer and the IP address of the same segment as the switch.

Step 2 Open the cmd window of the computer

Step 3 Enter Telnet + the management IP address of the switch (for example, if the management IP address of the switch is 192.168.0.1, enter Telnet 192.168.0.1)

Warranty Card

Customer	
Contact Person	
Telephone No.	
Purchase Date	
Purchase Address	
Product Model	
Product S/N	
Failure Description	
Dealer Signature	

- If the product defects within three months after purchase, we will provide you with a new product of the same model.
- If the product defects within two to three-year warranty period, we will provide professional maintenance service.
- Proof of purchase and a complete product serial number are required to receive any warranty service. Please keep your purchase receipt.
- Any other defects that are not caused by workmanship or product quality, such as natural disasters, water damage, extreme thermal or environmental conditions, stolen or unauthorized repair, are not covered by the limited product warranty.

Wireless Tek Technology Limited

Address:Building 3, Jinmo 1983 1 1983-1 1972,

Guangming Road, Guangming District,

Shenzhen City, Guangdong Province, China

Tel:+86-755-23715667 Fax:+86-755-23715667

Suite 2105,Level 21,

Email:sales@wireless-tek.com

Technical Support:mail@wireless-tek.com

CE FC RoHS